

Retro System Rescue (<http://retrosystemrescue.com>)

Attaching a Colecovision Power Cable

1. Slide the wire through the hole in the back of the case
2. Remove the black insulator to expose 2" of wire – do not remove the insulators of the 4 individual wires
3. Strip off about ¼" of insulator from each of the 7 wires
4. Attach the wires. You can use comp on terminals if you wish
 - a. Attach the yellow wire to the 4th terminal from the right
 - b. Attach the red wire to the 3rd terminal from the right
 - c. Attach the blue wire to the 2nd terminal from the right
 - d. Attach the white wire to the 1st terminal from the right

If your wires do not have the proper colors then you can determine which one by using a meter to test current flow. When looking at the cable end the holes in the cable are numbered as such:

	2	3	
	O	O	
O			O
1			4

Wire for hole #1 goes to terminal #1

Wire for hole #2 goes to terminal #4

Wire for hole #3 goes to terminal #3

Wire for hole #4 goes to terminal #2